

## Care and Maintenance of Vinyl wrapped and Acrylic doors and associated Products

As with all timber based items our products should not be stored or installed in a newly plastered room or damp environment. If you need to store them for a while they should be kept flat, preferably in the room in which they are to be installed. This is of particular importance for tall/wardrobe doors.

To clean door surfaces use a soft clean cloth, dampened (not wet) with warm soapy water. Dry off with a soft dry cloth. Do not use aggressive cleaning liquids or such items as scouring pads.

These products are wrapped in a man-made material, as are all similar ones in the kitchen and bedroom industry, which will melt under hot temperatures. To avoid damage caused as a result of exposure to excessive heat please follow these simple guidelines:

- When installing doors adjacent to ovens or other heat sources always ensure doors are shielded by the use of heat deflector strips
- Never use an appliance that generates high levels of heat or concentrated steam (such as a toaster, kettle, pressure cooker or breadmaker) directly under or adjacent to a door or panel as this can cause damage.

Components damaged as a result of not following the above guidelines are not covered by the guarantee unless protected **by suitable heat strips and a suitable gap left for heat escape.**

It is important that the doors are treated with proper care and attention.

All high gloss products should be allowed to 'cure' for seven days after removing the protective film. Please treat very carefully during this period and avoid cleaning or wiping as much as possible

To clean the surface of the doors, wipe using a soft cloth with a mild non-abrasive, dishwashing detergent diluted in water. The mix should be 1 part detergent to 99 parts water. You should never use any vinegar-based detergents, solvents, abrasive detergents, white spirit or furniture polish.

We recommend the use of VuPlex polish with a micro anti-scratch cloth.